



**B-SERIES CUMMINS HEAD STUD KIT
24 VALVE ENGINES, 12MM, ARP2000
PART NUMBER: HMR 1054008**



INSTALLATION INSTRUCTIONS

NOTE: THERE ARE 6 STUDS THAT HAVE MORE THREADS. THEY MUST BE INSTALLED ON THE EXHAUST MANIFOLD SIDE OF THE ENGINE.

WITH HEAD OFF:

1. Take a 12mm x 1.75 bottoming tap and clean holes in the block.
2. Install by hand a stud in each hole of the block, verifying that the chamfered shoulder on the stud bottoms out in the block. If it does not, remove stud, tap hole deeper with the bottoming tap, re-check for proper fit.
3. Remove studs
4. Install head on block, not forgetting head gasket
5. Coat threads of studs with motor oil (Use a conservative amount of oil. A small paint brush is best for applying the oil) before installing in block. Install studs in block – SNUG. DO NOT TORQUE STUDS IN BLOCK
6. Place flat washers on studs, lube washer and upper (fine) threads with ARP Assembly Lube. Torque to: 50 Ft LB, 100 Ft Lb and 125 Ft Lb
7. Recheck all studs at 125 Ft Lb final torque.
8. **RETORQUE PROCEDURE:**
 - a. Leave valve cover off, start truck and let run until it reaches operating temperature.
 - b. Retorque studs to 125# FT LB.
 - c. Check valves, re-adjust if necessary. INTAKE - .008 and EXHAUST - .018 on hot engine

FOR BEST RESULTS: WE ARE RECOMMENDING THAT YOU DRIVE THE TRUCK EASY FOR A WEEK AND RETORQUE AGAIN. REPEAT THE WEEKLY PROCEDURE UNTIL THE HEAD GASKET IS PROPERLY SEATED. CHECK PERIODICALLY.

